

APTIV™ FILMS 1103

General Information

Product Description

APTIV 1100 series films are the mineral filled semi-crystalline films made from VICTREX™ PEEK polymer. The film provides a material solution for engineers in ultra-high performance applications.

APTIV films are a comprehensive range of versatile, high-performance films, the use of which can facilitate reduced systems costs, improved performance and enhanced design freedom.

APTIV 1100 has a unique combination of properties providing high temperature performance, mechanical strength, durability, excellent radiation, hydrolysis and chemical resistance, electrical insulation, excellent barrier properties with high purity, good flammability without the use of flame retardants, low toxicity of combustion products, and low moisture absorption in a film format. Inherently halogen free and ease of processing makes APTIV films a technology enabler for our customers and end users. APTIV 1100 series provides a higher modulus and lower coefficient of linear thermal expansion over the APTIV 1000 series.

Material Properties

| Physical | Nominal Value | Unit | Test Method |
|---|---------------|-------------------|-------------|
| Density (23°C) | 1.54 | g/cm ³ | ISO 1183 |
| Water Absorption ¹ | | | ISO 62 |
| Equilibrium, 23°C, 0.0500 mm, 50% RH | 0.090 | % | |
| ShrinkageMD ² (200°C, 50.0 µm) | < 0.50 | % | |
| ShrinkageTD ² (200°C, 50.0 µm) | < 0.50 | % | |
| Films | Nominal Value | Unit | Test Method |
| Film Thickness - Recommended / Available | 12 to 125 | µm | |
| Tensile Modulus | | | ISO 527-3 |
| MD : 23°C, 25 µm | 5500 | MPa | |
| TD : 23°C, 25 µm | 4500 | MPa | |
| MD : 23°C, 50 µm | 5500 | MPa | |
| TD : 23°C, 50 µm | 4500 | MPa | |
| MD : 23°C, 100 µm | 5000 | MPa | |
| TD : 23°C, 100 µm | 4500 | MPa | |
| Tensile Stress | | | ISO 527-3 |
| MD : Break, 23°C, 25 µm | 70.0 | MPa | |
| TD : Break, 23°C, 25 µm | 70.0 | MPa | |
| MD : Break, 23°C, 50 µm | 90.0 | MPa | |
| TD : Break, 23°C, 50 µm | 90.0 | MPa | |
| MD : Break, 23°C, 100 µm | 90.0 | MPa | |
| TD : Break, 23°C, 100 µm | 90.0 | MPa | |
| Tensile Elongation | | | ISO 527-3 |
| MD : Break, 23°C, 25 µm | > 10 | % | |
| TD : Break, 23°C, 25 µm | < 10 | % | |
| MD : Break, 23°C, 50 µm | > 10 | % | |
| TD : Break, 23°C, 50 µm | < 10 | % | |
| MD : Break, 23°C, 100 µm | > 5.0 | % | |
| TD : Break, 23°C, 100 µm | < 10 | % | |

APTIV™ FILMS 1103

| Films | Nominal Value | Unit | Test Method |
|--|---------------|-------------------|-----------------|
| Trouser Tear Resistance ³ | | | ISO 6383-1 |
| MD : 50 µm | 5.00 | N/mm | |
| TD : 50 µm | 6.00 | N/mm | |
| Puncture Resistance (23°C, 50.0 µm) | 4 | kJ/m ² | Internal Method |
| Thermal | Nominal Value | Unit | Test Method |
| CLTE - Flow ⁴ (0.0500 mm) | 1.8E-5 | cm/cm/°C | ASTM D696 |
| Thermal Conductivity | | | ASTM E1461 |
| -- ⁵ | 0.61 | W/m/K | |
| -- ⁶ | 1.3 | W/m/K | |
| Electrical | Nominal Value | Unit | Test Method |
| Volume Resistivity ⁷ (23°C, 50 µm) | 1.0E+16 | ohms·cm | ASTM D257 |
| Dielectric Strength ⁸ (23°C, 50 µm) | 200 | kV/mm | ASTM D149 |
| Dielectric Constant (23°C, 50 µm, 10 MHz) | 3.5 | | ASTM D150 |
| Dissipation Factor (23°C, 50 µm, 10 MHz) | 1.0E-3 | | ASTM D150 |

Notes

¹ 24 hrs

² TM-VX-84

³ 23°C

⁴ below Tg

⁵ Through Plane

⁶ In-Plane

⁷ 100 V

⁸ 0.25 inch electrode

Revision Date: November 2023

This information is provided "as is". It is not intended to amount to advice. Use of the product is at the customer's/user's risk. It is the customer's/user's responsibility to thoroughly test the product in each specific application to determine its performance, efficacy and safety for each end-use product, device or other application and compliance with applicable laws, regulations and standards. Mention of a product is no guarantee of availability. Victrex reserves the right to modify products, data sheets, specifications and packaging. **Victrex makes no warranties, express or implied (including, without limitation, any warranty of fitness for a particular purpose or of intellectual property non-infringement) and will not be liable for any loss or damage of any nature (however arising) in connection with customer's/user's use or reliance on this information, except for any liability which cannot be excluded or limited by law.** This document may be modified or retracted at any time without notice to the customer/user.

Victrex Manufacturing Limited (or another member of the Victrex group) is the owner or the licensee of all intellectual property rights in and to this document including the following trademarks, VICTREX, 450G, VICTREX AM, VICTREX CT, VICTREX FG, VICTREX HPG, VICTREX HT, VICTREX ST, VICTREX WG, APTIV, LMPAEK, VICOTE, TRIANGLE (Device). All rights are protected by intellectual property rights including copyright under relevant national and international intellectual property laws and treaties. All rights reserved. Copyright © Victrex Manufacturing Limited 2025.