



VICOTE™ COATINGS F807BLK

General Information

Product Description

VICOTE F807Blk (Black) is an Aqueous Dispersion for Use on Ferrous and Non-Ferrous Metals

VICOTE is the brand name for the Victrex range of coatings. VICOTE Coatings are available through Victrex or its preferred coater network.

The F807Blk (Black) has been specifically formulated to provide a tough, resilient, high wear resistant coating with varying levels of lubricants on ferrous and non-ferrous substrates such as carbon steel, cast steel and aluminium. Typical properties are high continuous use temperature of 260°C, exceptional wear, abrasion and cut through resistance at these high temperatures combined with excellent chemical resistance. VICOTE dispersions have a low level of extractables. These properties are retained at high temperatures where other release coatings may potentially fail. Contact Victrex for further details.

VICOTE F807Blk (Black) Dispersions

VICOTE F807Blk (Black) is aqueous based however there are small amounts of solvents present. Refer to the appropriate MSDS sheet for details.

The VICTREX™ PEEK polymer contained in the VICOTE dispersions like other non-coating grades of VICTREX PEEK polymer is thermoplastic in nature and exhibit flow above the melt temperature. When processed using the correct guidelines the coatings will exhibit the excellent properties that VICTREX PEEK polymer is renowned for.

VICOTE Coatings have excellent chemical resistance. Consult the Victrex Chemical Resistance brochure for further details.

SUBSTRATES AND PREPARATION

VICOTE Coatings can be applied to most ferrous metals. A primer is not required. Cast metals need to be de-gassed in an oven to prevent pin holes in the coating surface.

Substrates should be free from grease, oils and corrosion prior to coating. Solvent de-greasing and grit blasting with aluminium oxide with final solvent wash should ensure a suitable surface for coating. Note: phosphate pre-treated substrates are not recommended for VICOTE grades as the high processing temperatures required for processing can result in de-lamination of the coating.

SPRAYING

A conventional gravity fed spray gun with a nozzle size between 0.7 and 1.0mm has been found suitable for applying VICOTE dispersions. Edges of components should be sprayed first before applying a complete coating. An air pressure to the gun of between 35 and 50 psi has been found to be a suitable spray pressure. Spray at right angles to the substrate wherever possible. The spray gun and cup can be cleaned with water after use.

PROCESSING

For general processing information consult the 10-step guide for VICOTE Dispersion Coatings. Coated parts should be dried in air for 5 minutes then dried in an oven for 5 minutes at 120°C before placing in an oven at 400°C to melt and fuse the coating. By following the processing guide smooth coatings should be achievable. Because VICOTE materials are semi crystalline thermoplastics, as with all these types of products shrinkage will take place when the coating cools. The mass of the substrate, coating thickness and rate of cooling will determine the amount of shrinkage.

Normally processed and cooled coatings should result in semi-crystalline coatings which should not require further post processing treatment. However, an increase in crystallinity may enhance certain properties such as wear and scratch resistance. To anneal the coating the part should be placed in an air circulating oven and the temperature raised at 10°C per minute to 250°C and held at that temperature for 30 minutes to 1 hour.

With coated parts that are subject to a high service temperature it may be beneficial to anneal the parts at 10°C above the maximum service temperature to prevent further volume change of the coating. Note: The colour of the final coating when using VICOTE F805 natural may depend on the substrate. For example, VICOTE Coating processing temperatures will turn some steels blue and may impart a blue/grey colour to the final VICOTE coating.

STORAGE AND HANDLING CONSIDERATIONS

VICOTE Coatings drums should be stored in a clean dry environment and should not be stored with the lids removed as this may result in airborne dust contaminating the product, which could cause coating defects.

VICOTE™ COATINGS F807BLK

The VICOTE dispersions will soft settle after prolonged standing. They can be re-dispersed readily by stirring of the liquid suspension. The drums can also be rolled to agitate the dispersion to ensure homogeneity. High shear dispersing should be avoided as the wetting agent is prone to shear thinning. It is recommended that the dispersions are not allowed to freeze. Optimum storage temperature is 5 – 25°C.

VICOTE F807Blk (Black) is packed in 20 kg polythene UN drums enclosed in a strong cardboard box with the VICOTE logo.

SAFETY PRECAUTIONS

Before applying VICOTE dispersions, read the appropriate Material Safety Data Sheet (MSDS) and the 10-step guide for VICOTE Dispersion Coatings, available from Victrex.

VICOTE F807Blk (Black) dispersions must only be applied where Local Extract Ventilation (LEV) is available with the gasses removed completely from the work area. The hot gasses given off during melt processing can cause flu like symptoms. Care should be taken not to inhale such gasses; also contact of the polymer with tobacco products should be avoided. Washing of hands and good housekeeping are a prerequisite before and after handling these products.

Material Properties

Mechanical	Nominal Value	Unit	Test Method
Coefficient of Friction@ 10 min. ¹	0.165	µm	ASTM G133
Thermal	Nominal Value	Unit	Test Method
Glass Transition Temperature ²			ISO 11357-2
Onset	143	°C	
Midpoint	147	°C	
Melting Temperature ²	343	°C	ISO 11357-3
Additional Information	Nominal Value	Unit	Test Method
Cross Hatch AdhesionAluminum ³	0		ISO 2409
Cross Hatch AdhesionMild Steel ³	0		ISO 2409
Cross Hatch AdhesionStainless Steel ³	0		ISO 2409
Direct ImpactHeight	1	m	ISO 6272-1
Direct ImpactIndentation depth	5	mm	ISO 6272-1
Direct ImpactWeight	2	kg	ISO 6272-1
Konig Hardness ⁴ (40.0 to 50.0 µm)	140	sec	ISO 1522

Typical Property Data for VICOTE F807BLK Coating on Film Thickness 25 - 30 µm

Notes

¹ Using 100N Load

² Thermal analysis data of the PAEK polymer used in the VICOTE coating formulation

³ Rating 0 to 5

⁴ Minimum coating thickness required for this test was 30 µm

Revision Date: October 2024

This information is provided "as is". It is not intended to amount to advice. Use of the product is at the customer's/user's risk. It is the customer's/user's responsibility to thoroughly test the product in each specific application to determine its performance, efficacy and safety for each end-use product, device or other application and compliance with applicable laws, regulations and standards. Mention of a product is no guarantee of availability. Victrex reserves the right to modify products, data sheets, specifications and packaging. **Victrex makes no warranties, express or implied (including, without limitation, any warranty of fitness for a particular purpose or of intellectual property non-infringement) and will not be liable for any loss or damage of any nature (however arising) in connection with customer's/user's use or reliance on this information, except for any liability which cannot be excluded or limited by law.** This document may be modified or retracted at any time without notice to the customer/user.

Victrex Manufacturing Limited (or another member of the Victrex group) is the owner or the licensee of all intellectual property rights in and to this document including the following trademarks, VICTREX, 450G, VICTREX AM, VICTREX CT, VICTREX FG, VICTREX HPG, VICTREX HT, VICTREX ST, VICTREX WG, APTIV, LMPAEK, VICOTE, TRIANGLE (Device). All rights are protected by intellectual property rights including copyright under relevant national and international intellectual property laws and treaties. All rights reserved. Copyright © Victrex Manufacturing Limited 2025.